



# **BOWLE QUICK START GUIDE**



# **BOWLE OVERVIEW**



Lock/Unlock :: Click B 3 times (quickly).

Start (Unlocked) :: Click B

Change Power Level :: Click C to cycle.

Check Battery :: Hold and release B + C

## **POWER & CHARGING**

- Bowle must be charged before first use.
- The battery charging level is indicated with blue LEDs.



- A fully charged battery is indicated with all blue LEDs flashing simultaneously and switching off when plugged in to charge.
- Only charge Bowle with the supplied cable and charger.

## 2 BOWLE USER & METHOD

- 1 Cycle power to desired level with C Power Level Button.
  - Low Medium High Very High
- Click and release B the large Fire button.Once the oven is up to temperature, the LEDs will turn solid green.
- Begin inhalation immediately from mouthpiece as soon as LEDs turn solid green (smooth and long, steady inhalation recommended).



#### ALTERNATE POWER USE METHOD: BETTER BATTERY LIFE AND USER CONTROL

After cyling to desired power level with the Power Level button, click and hold down the large Fire button.


Once the LEDs turn green, begin inhalation while continuing to hold down the large fire button.

Release the Fire button once single inhalation is complete.


Inhale with a similar pace and effort of a large drinking straw.

Tafée recommends 6 seconds of steady inhalation.


## 3 LOADING BOWLE WITH POTTER




Load <u>pinky-sized</u> herbs <u>in between</u> top shredder.(No more than a half gram in total. Less is more.)




2 Flip Potter <u>upside-down</u> and rotate to shred.
(At least 5 clockwise and anti-clockwise rotations. Take care to firmly hold all sections together.)




3 Flip Potter <u>right-side-up</u> and rotate to disperse into Oven Pots. (At least 5 clockwise and anti-clockwise rotations. Take care to firmly hold all sections together.)



4 Lightly tap Potter on a flat surface.(Take care to firmly hold all sections together)



5 Gently separate the top and mid sections to reveal 4 filled pots. (Take care to open top and mid sections in a clam shell manner)



6 Place Oven Pot in detached stem and insert stem into Puck Base Unit.



Optional: To use Bowle with drinkware. Place supplied drinkware unit on Bowle before pouring in your drink of choice.

Do not clean or soak Potter or the Drinkware with any isopropyl. See care and maintenance guide and manual.

## 4 DETACHING BOWLE STEM AND OPTIONAL DRINKWARE



## **5** CARE AND MAINTENANCE

Ceramic Oven Pots: For best performance, always empty Ceramic Pots shortly after each session to reduce buildup in stainless steel screen. Clean after significant build up clogs stainless steel screen airflow.

To clean, soak in isopropyl alcohol for up to 12 hours and rinse thoroughly in clean water after stainless steel screen bottom becomes clogged from extended use. REMOVE THE O-RING GASKET AROUND THE CERAMIC POT PRIOR TO SOAKING. The O-ring gasket never needs to be cleaned. Do not immerse it in isopropyl. Do not separate the stainless steel from the ceramic pot when cleaning.

**Stem:** Soak for up to 12 hours in isopropyl and rinse thoroughly in clean water only after significant buildup is observed over extended use and taste of aroma becomes affected noticeably. Dry thoroughly and completely after rinsing.

Mouthpiece: Wash with dish soap and rinse thoroughly in warm water after extended use.

**Drinkware:** Hand wash with soft towel in warm water and dry with extra soft drying towel. Alternatively load in top side of dishwasher. Do not heat dry.

Thank you kindly for your support.

Visit tafee.com full operating manual and guides.

Visit the website for customer service or call 18 HI MY TAFEE

Mon - Fri, 11am – 4pm EST

Email info@tafee.com for support.

### WARRANTY

Tafée™ guarantees to you that if used for its intended purpose the Bowle® will be free from defects in material or workmanship caused by the manufacturing process for the warranty period of two years.

This warranty does not cover accessories or device parts exposed to normal use, such as the Mouthpiece, Drinkware, Stem, Ceramic Oven Pots and Herb Shredder.

To activate your warranty, please register your product at tafee.com.

#### **USER PRECAUTIONS**

Major changes in the environment (external conditions) may cause the Bowle® to malfunction.

Always protect the Puck against liquids, rain or humidity, and high temperatures, including direct sunlight.



Handle with care Ceramic Oven Pots are hot surfaces that can exceed 50°C.